

Forbo FloorCare method Xad8/afVJ/

Cleaning after installation



- Vacuum clean the floor using an upright vacuum cleaner with a powered brush
- · Remove stains or spills locally using clean warm water
- Always work from outside inwards
- Remove excess water
- Allow the floor to dry

Regular cleaning



- Vacuum clean the floor using an upright vacuum cleaner with a powered brush
- Remove stains or spills locally using clean warm water
- Always work from outside inwards
- Remove excess water
- Allow the floor to dry

Occasional maintenance





- First soak stains locally by spraying with a solution of mild detergent
- Scrub with plenty of warm water, using a machine for carpet wet cleaning with brush action
- Allow the floor to dry